



INSTRUCTIONS

SILLOSOCKS MOTORISED PIGEON FLAPPER

What's in the Box?

1 X Pigeon Body

2 x Wing Spars

Operation

1. To insert the wing spars, hold the decoy and unfold one wing towards you. Fold the wing slightly in the middle where the mid-wing cut out is and thread the un-covered end of the spar underneath the flap.
2. Insert the spar into the wing socket and ensure it is fully seated. See photo.



3. Flex the spar to insert the capped end into the wing tip pocket and ensure it is fully seated.
4. Repeat 1 – 3 for the opposite wing.
5. Connect to your battery and test for several cycles to ensure the spars are placed correctly and to familiarise yourself with setting out in the field. Push once for intermittent and again for always on, once more for off.
6. Remove spars when travelling to avoid damaging the sockets and wing pockets.

If you have any questions or suggestions or would like to order more... then please feel free to contact us using any of the means listed below.

Through our website: www.ukshootwarehouse.com

By email: sales@ukshootwarehouse.com

By phone: 02476 329 510

Or for the social media savvy, you can find us on Facebook at www.facebook.com/ukshoot or Follow us on Twitter @theukshoot. You can post your ideas, comments and feedback - and post pictures too!

Happy and Safe Hunting from the team at UKShootWarehouse.com!

Please exercise caution when using this product UK Shootwarehouse accept no liability for accidents however caused whilst using this equipment.